

**Current Products (as May 14, 2026)**

The product, in accordance with the Ecodesign Requirements for Energy Related Products Directive 2009/125/EC and the Ecodesign for Energy-Related Products and Energy Information (Amendment) (EU Exit) Regulations 2020, is in compliance with the following norm(s) or document(s): Commission Regulation (EU) 2023/826.

**QuietComfort Headphone**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	<b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, Slide the Power/Bluetooth switch to the right and hold for 3 seconds until you hear “Ready to connect” and the status light blinks blue. To deactivate, slide the Power/Bluetooth switch to the left. See page 26 of the owner’s guide for more details.	
<b>Use only USB power supply with minimum output current/power rating of 0.5A/2.5W</b>		

**QuietComfort Ultra Headphone**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	<b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, with the headphones powered on, press and hold the Bluetooth/Power button. You hear the power off tone and the status light blinks white twice. Continue holding until you hear “Ready to connect” and the status light blinks blue. To deactivate, press and hold the Bluetooth/Power button and multi-function button simultaneously until you hear “Bluetooth device list cleared. Ready to connect.” See pages 41 and 42 of the owner’s guide for more details.	
<b>Use only USB power supply with minimum output current/power rating of 0.5A/2.5W</b>		

**QuietComfort Ultra Headphone (2ND GEN)**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	<b>Bluetooth®:</b> Activate by pairing with a Bluetooth source. Deactivate by clearing the pairing list by pressing and holding the Bluetooth button and multi-function button simultaneously, see page 30.	
<i>Use only USB power supply with minimum output current/power rating of 0.5A/2.5W</i>		

**QuietComfort Earbuds**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	<b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, touch and hold either earbud for 4 seconds until you hear “Ready to pair”. To deactivate, place both earbuds in the charging case. See pages 41 and 42 of the owner’s guide for more details.	
<i>Use only USB power supply with minimum output current/power rating of 0.65A/3.25W</i>		

**QuietComfort Ultra Earbuds**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	<b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, With the earbuds in the charging case and the case open, press and hold the button on the back of the case until the earbuds status light slowly blinks blue. To deactivate, place both earbuds in the charging case. See pages 43 and 45 of the owner's guide for more details.	
<b>Use only USB power supply with minimum output current/power rating of 1.2A/6W</b>		

**QuietComfort Ultra Earbuds (2ND GEN)**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	<b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, With the earbuds in the charging case and the case open, press and hold the button on the back of the case until the earbuds status light slowly blinks blue. To deactivate, place both earbuds in the charging case. See pages 44 – 48 of the owner's guide for more details.	
<b>Use only USB power supply with minimum output current/power rating of 1.2A/6W</b>		

### Ultra Open Earbuds

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	<b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, press and hold the Bluetooth button until you hear “Ready to connect” and the Bluetooth light slowly blinks blue. To deactivate, place both earbuds in the charging case. See pages 34 and 37 of the owner’s guide for more details.	
<b>Use only USB power supply with minimum output current/power rating of 1A/5W</b>		

### SoundLink Flex Portable Speaker (2<sup>nd</sup> Gen)

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	<b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, press and hold the Bluetooth button until you hear “Ready to connect” and the Bluetooth light slowly blinks blue. To deactivate, Press and hold the Bluetooth button for 15 seconds until you hear “Bluetooth device list cleared. Ready to connect” and the Bluetooth light blinks blue.	
<b>Use only USB power supply with minimum output current/power rating of 1.5A/7.5W</b>		

**SoundLink Max Portable Speaker**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	<p><b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, press and hold the Bluetooth button until you hear “Ready to connect” and the Bluetooth light slowly blinks blue. To deactivate, Press and hold the Bluetooth button for 15 seconds until you hear “Bluetooth device list cleared. Ready to connect” and the Bluetooth light blinks blue.</p>	
<p><b>Use only USB power supply with minimum output current/power rating of 3A/15W</b></p>		

**SoundLink Plus Portable Speaker**

Required Power State Information	Power Modes	
	Off Mode	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	N/A*
Time after which equipment is automatically switched into mode	≤ 20 minutes	N/A*
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	N/A*
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	<p><b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, press and hold the Bluetooth button until you hear “Ready to connect” and the Bluetooth light slowly blinks blue. To deactivate, Press and hold the Bluetooth button for 15 seconds until you hear “Bluetooth device list cleared. Ready to connect” and the Bluetooth light blinks blue.</p> <p>*Soundlink Plus portable speaker goes to off mode after 20 minutes of no activity.</p>	
<p><b>Use only USB power supply with minimum output current/power rating of 3A/15W</b></p>		

**SoundLink Micro Bluetooth Speaker (2<sup>nd</sup> Gen)**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	<b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, press and hold the Bluetooth button until you hear “Ready to connect” and the Bluetooth light slowly blinks blue. To deactivate, Press and hold the Bluetooth button for 15 seconds until you hear “Bluetooth device list cleared. Ready to connect” and the Bluetooth light blinks blue.	
<b>Use only USB power supply with minimum output current/power rating of 1.5A/7.5W</b>		

**SoundLink Home Bluetooth® Speaker**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	<b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, press and hold the Bluetooth button until you hear “Ready to connect” and the Bluetooth light slowly blinks blue. To deactivate, Press and hold the Bluetooth button for 10 seconds until you hear “Bluetooth device list cleared and the Power light blinks white twice.	
<b>Use only USB power supply with minimum output current/power rating of 1.5A/7.5W</b>		

### Bose Smart Soundbar

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
<p>Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby. *</p> <p>* Prior to deactivating networks or entering standby mode, use the microphone on/off button to ensure the microphone is turned on (the red indicator light will be off).</p>	<p>Wi-Fi®: Activate using the Bose app. Deactivate by pressing and holding the Mute and Bluetooth buttons on the remote simultaneously.</p> <p>Bluetooth®: Activate by pairing with a Bluetooth source by pressing the Bluetooth button on the remote then selecting the soundbar in your device Bluetooth list or by using the Bose app. Deactivate by clearing the pairing list by pressing and holding the Bluetooth button on the remote for 10 seconds.</p>	

### Bose Smart Ultra Soundbar

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wired and wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
<p>Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby. *</p> <p>* Prior to deactivating networks or entering standby mode, use the microphone on/off button to ensure the microphone is turned on (the red indicator light will be off).</p>	<p>Wi-Fi®: Activate using the Bose app. Deactivate by pressing and holding the Mute and Bluetooth buttons on the remote simultaneously.</p> <p>Bluetooth®: Activate by pairing with a Bluetooth source by pressing the Bluetooth button on the remote then selecting the soundbar in your device Bluetooth list or by using the Bose app. Deactivate by clearing the pairing list by pressing and holding the Bluetooth button on the remote for 10 seconds.</p>	
Wired network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Ethernet: To activate an Ethernet connection, connect one end of an Ethernet cable to the Ethernet port on the soundbar and the other end to an Ethernet source. To deactivate, remove the Ethernet cable.	

**TV Speaker**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	Bluetooth ≤ 2.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	Bluetooth®: Activate by pairing with a Bluetooth source by pressing the Bluetooth button on the remote then selecting the soundbar in your device Bluetooth list or by using the Bose app. Deactivate by clearing the pairing list by pressing and holding the Bluetooth button on the remote for 10 seconds.	

**Solo Soundbar II**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	≤0.5 W	N/A*
Time after which equipment is automatically switched into mode	≤ 20 minutes	N/A*
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	N/A*
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.	*Product does not utilize a networked standby mode for a Bluetooth® connection	
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands
	Model identifier	DT20V-1.8C-DC
	Input voltage	100V-240V
	Input AC frequency	50Hz/60Hz
	Output voltage	20V DC
	Output current	1.8A
	Output power	36W
	Average active efficiency	89.0%
	Efficiency at low load (10%)	88.3%
	No-load power consumption	0.08W

### Bose Music Amplifier

Required Power State Information	Power Modes	
	Standby	Networked Standby
	This product is equipment with HiNA functionality	
Power consumption in specified power mode, at 230V/50Hz input	≤ 0.5 W	all network types ≤ 3.0 W
Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 20 minutes
Power consumption in networked standby if all wired and wireless network ports are activated, at 230V/50Hz input	N/A	≤ 3.0 W
<p>Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby. *</p> <p>* Prior to deactivating networks or entering standby mode, use the microphone on/off button to ensure the microphone is turned on (the red indicator light will be off).</p>	<p>Wi-Fi®: Activate using the Bose app. Deactivate by pressing and holding the Mute and Bluetooth buttons on the remote simultaneously.</p> <p>Bluetooth®: Activate by pairing with a Bluetooth source by pressing the Bluetooth button on the remote then selecting the soundbar in your device Bluetooth list or by using the Bose app. Deactivate by clearing the pairing list by pressing and holding the Bluetooth button on the remote for 10 seconds.</p> <p>Supplemental Mode: To deactivate and set the amplifier to Main, flip the ADVANCED SETTINGS switch A to the up position.</p>	
Wired network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Ethernet: To activate an Ethernet connection, connect one end of an Ethernet cable to the Ethernet port on the soundbar and the other end to an Ethernet source. To deactivate, remove the Ethernet cable.	

### Bass Module 500

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	N/A *	all network types ≤ 2.0 W
Time after which equipment is automatically switched into mode	N/A *	≤ 20 minutes
Power consumption in networked standby if all wired and wireless network ports are activated, at 230V/50Hz input	N/A	≤ 2.0 W
Network port deactivation/activation procedures. Deactivating all networks will enable standby.	*Per Annex III 2(d) of Commission Regulation (EU) 2023/826, the requirement to deactivate a wireless port “does not apply to equipment that relies on a single wireless network connection for intended use and have no wired network connection.”	

**Bass Module 700**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	N/A *	all network types $\leq 2.0$ W
Time after which equipment is automatically switched into mode	N/A *	$\leq 20$ minutes
Power consumption in networked standby if all wired and wireless network ports are activated, at 230V/50Hz input	N/A	$\leq 2.0$ W
Network port deactivation/activation procedures. Deactivating all networks will enable standby.	*Per Annex III 2(d) of Commission Regulation (EU) 2023/826, the requirement to deactivate a wireless port “does not apply to equipment that relies on a single wireless network connection for intended use and have no wired network connection.”	

**Surround Speakers**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	N/A *	all network types $\leq 2.0$ W
Time after which equipment is automatically switched into mode	N/A *	$\leq 20$ minutes
Power consumption in networked standby if all wired and wireless network ports are activated, at 230V/50Hz input	N/A	$\leq 2.0$ W
Network port deactivation/activation procedures. Deactivating all networks will enable standby.	*Per Annex III 2(d) of Commission Regulation (EU) 2023/826, the requirement to deactivate a wireless port “does not apply to equipment that relies on a single wireless network connection for intended use and have no wired network connection.”	

**Surround Speakers 700**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	N/A *	all network types $\leq 2.0$ W
Time after which equipment is automatically switched into mode	N/A *	$\leq 20$ minutes
Power consumption in networked standby if all wired and wireless network ports are activated, at 230V/50Hz input	N/A	$\leq 2.0$ W
Network port deactivation/activation procedures. Deactivating all networks will enable standby.	*Per Annex III 2(d) of Commission Regulation (EU) 2023/826, the requirement to deactivate a wireless port “does not apply to equipment that relies on a single wireless network connection for intended use and have no wired network connection.”	

**Lifestyle Ultra Speaker**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	$< 0.5$ W*	all network types $\leq 2.0$ W
Time after which equipment is automatically switched into mode	$\leq 20$ minutes	$\leq 20$ minutes
Power consumption in networked standby if all wireless network ports are activated, at 230V/50Hz input	N/A	$\leq 2.0$ W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.  <b>Note:</b> *Prior to deactivating wireless networks or entering standby, tap the Microphone off button to turn the microphone on. The Microphone off light turns off.	<p><b>Wi-Fi®:</b> To deactivate/activate Wi-Fi capability, touch and hold the <i>Bluetooth</i> button and the Play/Pause button for 5 seconds until the status light blinks green twice.</p> <p><b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, tap the <i>Bluetooth</i> button. The status light slowly pulses blue. In your device’s <i>Bluetooth</i> settings, select the speaker from the list of available products. To deactivate, on the speaker, touch and hold the <i>Bluetooth</i> button for 10 seconds until the status light blinks white twice.</p>	

**Lifestyle Ultra Soundbar**

Required Power State Information	Power Modes	
	This product is equipment with HiNA functionality	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	< 0.5 W*	all network types ≤ 3.0 W
Time after which equipment is automatically switched into mode		
Power consumption in networked standby if all wired network ports are connected and all wireless network ports are activated, at 230V/50Hz input	≤ 20 minutes	≤ 20 minutes
	N/A	≤ 3.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby.  <b>Note:</b> * Prior to deactivating wireless networks or entering standby, tap the Microphone off button to turn the microphone on. The Microphone off light turns off.	<p><b>Wi-Fi®:</b> To deactivate/activate Wi-Fi capability, touch and hold the <i>Bluetooth</i> button I and the Play/Pause button F for 5 seconds until the status light blinks green twice.</p> <p><b>Bluetooth®:</b> To activate a <i>Bluetooth</i> connection, tap the <i>Bluetooth</i> button I. The status light slowly pulses blue. In your device's <i>Bluetooth</i> settings, select the soundbar from the list of available products. To deactivate, on the soundbar, touch and hold the <i>Bluetooth</i> button I for 10 seconds until the status light blinks white twice.</p>	
Wired network port deactivation/activation procedures. Deactivating all networks will enable standby mode.  <b>Note:</b> Prior to deactivating wired networks or entering standby, tap the Microphone off button to turn the microphone on. The Microphone off light turns off.	<p><b>HDMI:</b> To activate an HDMI connection, connect one end of an HDMI cable to the HDMI (eARC) port on the soundbar and the other end to an audio source. To deactivate, remove the HDMI cable.</p> <p><b>Ethernet:</b> To activate an Ethernet connection, connect one end of an Ethernet cable to the Ethernet port on the soundbar and the other end to an Ethernet source. To deactivate, remove the Ethernet cable.</p>	

**Lifestyle Ultra Subwoofer**

Required Power State Information	Power Modes	
	Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input	N/A*	Bose Wireless $\leq 2.0$ W
Time after which equipment is automatically switched into mode	N/A*	$\leq 20$ minutes
Power consumption in networked standby if all wired network ports are connected and all wireless network ports are activated, at 230V/50Hz input	N/A	$\leq 2.0$ W
Network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	*Per Annex III 2(d) of Commission Regulation (EU) 2023/826, the requirement to deactivate a wireless port “does not apply to equipment that relies on a single wireless network connection for intended use and have no wired network connection.”	